```
Service setup
```

so, let's setup HTTP, FTP, SSH, and MySQL

```
HTTP (default port 80)
```

```
We'll use Apache
```

sudo apt-get install apache2

Next, check that it is running (it should be on port 80):

```
sudo netstat -alpn | grep ' LISTEN '
...
tcp6 0 0 :::80 :::* LISTEN 7865/apache2
...
```

Try browsing to your web site using a web browser (e.g., Google Chrome)

http://localhost

Your web site's files are in /var/www

sudo nano /var/www/html/index.html

FTP (default port 21)

We'll use vsftpd (very secure FTP daemon)

sudo apt-get install vsftpd

Next, check that it is running (it should be on port 21):

```
sudo netstat -alpn | grep ' LISTEN '
...
tcp 0 0 0.0.0.0:21 0.0.0.0:* LISTEN 3309/vsftpd
...
```

Try logging in using your user credentials:

```
$ ftp localhost
{you should be in your home directory - try ls -lh)
{Ctrl+D disconnects you}
```

Let's modify the configuration to allow anonymous logins:

sudo nano /etc/vsftpd.conf

Restart the FTP server:

```
sudo service vsftpd restart
```

Try logging in again (this time, anonymously):

```
ftp localhost
{user is anonymous}
{password is blank (just press Enter)}
```

```
SSH (default port 22)
      We'll use OpenSSH
             sudo apt-get install openssh-server
      Next, check that it is running (it should be on port 22):
             sudo netstat -alpn | grep ' LISTEN '
                    0 0 0.0.0.0:22 0.0.0.0:* LISTEN 1091/sshd
            tcp
      Try logging in using your user credentials:
             ssh localhost
             {you should be in your home directory - try ls -lh}
             {Ctrl+D disconnects you}
      Where's the message of the day (MOTD)?
             sudo nano /etc/motd
            the file will most likely not exist
      Logging in as a different user (it must exist on your system) is easy:
             ssh user@localhost
      You can also disable password logins
            why? well, you can, instead, use encryption keys
            this is much more secure
      Make sure to add the following line to /etc/ssh/sshd_config
            this is important during labs, challenges, and Cyber Storm
            UseDNS no
MySQL (default port 3306)
      Of course, we'll use MySOL!
             sudo apt-get install mysql-server
            this will also prompt you for a root password
                   you should probably make it a good one
                   you should probably remember it
      Let's secure the MySQL server
             sudo mysql secure installation
                   I wouldn't worry about changing the root password
                   I would remove anonymous users
                   I would disable remote root logins
                   I would remove test databases
                   Yes, reload table privileges
      Next, check that it is running (it should be on port 3306):
             sudo netstat -alpn | grep ' LISTEN '
                    0 0 127.0.0.1:3306 0.0.0.0:* LISTEN 1389/mysqld
             tcp
             . . .
             127.0.0.1?
                   yup, it means that it only accepts local (not remote) connections
                   i.e., it is listening on the localhost only
```

```
Try logging in using root credentials:
            mysql -uroot -p
      So how do we accept remote connections?
            first, let's add a new user (to MySQL and not the entire server)
            we need to login to the MySQL server first
                  mysal -uroot -p
            and now the new user
                  CREATE user 'dude'@'%' IDENTIFIED BY 'password';
                  % means that the user can connect from anywhere (including remotely)
            this user can now be used to login and view databases
            let's create a new database (as root)
                   CREATE DATABASE test;
            next, let's grant dude all privileges on the new database
                   GRANT ALL PRIVILEGES ON test.* TO 'dude'@'%';
                   FLUSH PRIVILEGES:
            now, let's login as the new user (Ctrl+D exits MySQL)
                   mysql -udude -p
            and let's see the databases (test should be there)
                   SHOW DATABASES;
      What about allowing remote access?
            sudo nano /etc/mysql/my.cnf
            note, on newer versions of MySQL, the config file has changed
            sudo nano /etc/mysql/mysql.conf.d/mysqld.cnf
            comment out the bind-address option
                   #bind-address
                                                  = 127.0.0.1
            note, on newer versions of MySQL, you will need to bind to 0.0.0.0
                  bind-address
                                                = 0.0.0.0
            restart the server
                   sudo service mysql restart
            next, check that it is listening remotely:
                   sudo netstat -alpn | grep ' LISTEN '
                          0 0.0.0.0:3306 0.0.0.0:* LISTEN 1091/mysqld
                   tcp
Changing ports
      In most cases, the default port is specified in a configuration file
            So you just need to change it
      You will need to restart the appropriate server after changing the port
      You can check that it is listening on the new port (via netstat)
      Of course, try logging in again on the new port
      HTTP
            sudo nano /etc/apache2/ports.conf
            Listen 80
            {you should change to a different port; e.g., 12345}
            sudo nano /etc/apache2/sites-enabled/000-default.conf
            Change the following line to match the new port:
                   <VirtualHost *:12345>
```

```
Restart the server
            sudo service apache2 restart
      Browse to the new port in a web browser
            http://localhost:12345
FTP
      sudo nano /etc/vsftpd.conf
      Add the following line to match the new port:
            listen port=54321
      Restart the server
            sudo service vsftpd restart
      Login on the new port
            ftp localhost 54321
SSH
      sudo nano /etc/ssh/sshd config
      Port 22
      {you should change to a different port; e.g., 2222}
      Restart the server
            sudo service ssh restart
      Login on the new port
            ssh -p 2222 localhost
MySQL
      sudo nano /etc/mysql/my.cnf
      Note, on newer versions of MySQL, the config file has changed
      sudo nano /etc/mysql/mysql.conf.d/mysqld.cnf
      Find the [client] section and change the port
                                = 3306
            port
            {you should change to a different port; e.g., 6033}
      Find the [mysqld] section and change the port
                                = 3306
            port
            {you should change to a different port; e.g., 6033}
      Restart the server
            sudo service mysql restart
      Login on the new port
            mysql -h {your IP} -udude -p
```